

Micca Speck G2 Media Player Spec Sheet

If you've requested for a *media player* for the Grad Show:

- USB Flash Drive is preferred. Avoid using SD cards.
- USB Flash Drive must be formatted to **FAT32** (preferred) or **NTFS** format, and must not exceed 32GB.
- Place file(s) in the *root directory*. Do not place your artwork inside a folder. Remove files you don't need.
- If your work is audio or video-based, save it as **one file**. The media player may skip or not read multiple audio or video files.
- Preferred file extensions/formats:
 - Photo – JPG/PNG/GIF
 - Audio – MP3 (bit rate: 32kbps – 320kbps)
 - Video – MP4 (codec H.264), max 30fps, max stream 10mbps, NTSC (50Hz/60Hz)
- Max resolution is **1920x1080**.
- To loop your file, press the **REPEAT button** on the remote until "**Repeat One**" (for one file) or "**Repeat All**" (for multiple files) is shown on the screen.
- For more in-depth instructions, please download the manual using the QR code below.

